

C 30-01

**CHEVROLET  
ILLUSTRATED  
SPARE PARTS LIST  
30 CWT 4x4  
MODEL C 30 -- CHASSIS 8441  
134" WB**

**CANADIAN MILITARY PATTERN VEHICLE**

THIS PARTS LIST APPLIES TO ALL  
VEHICLES OF THIS MODEL FROM START  
OF PRODUCTION UP TO AND  
INCLUDING THOSE WITH SYMBOL C30-01  
ON PUBLICATIONS PLATE

**GENERAL MOTORS PRODUCTS OF CANADA, LTD.  
OSHAWA -- CANADA**



C 30 - 01

**CHEVROLET**  
**ILLUSTRATED**  
**SPARE PARTS LIST**  
**30 CWT 4x4**  
**MODEL C 30--CHASSIS 8441**  
**134" WB**  
**CANADIAN MILITARY PATTERN VEHICLE**

THIS PARTS LIST APPLIES TO ALL VEHICLES  
 OF THIS MODEL FROM START OF  
 PRODUCTION UP TO AND INCLUDING  
 THOSE WITH SYMBOL C30-01 ON  
 PUBLICATIONS PLATE

**GENERAL MOTORS PRODUCTS OF CANADA, LTD.**  
**OSHAWA - CANADA**

November, 1942

Lithographed in Canada

| Alphabetical Index              |              |
|---------------------------------|--------------|
| Engine—0.000                    | 0.000        |
| Clutch—0.795                    | 0.795        |
| Cooling—1.000                   | 1.000        |
| Oiling—1.426                    | 1.426        |
| Electrical                      | 2.004—2.999  |
| Fuel System                     | 3.000        |
| Carburetor                      | 3.725        |
| Pump—3.900                      | 3.900        |
| Transmission                    | 4.000—4.447  |
| Transfer Case                   |              |
| Winch                           |              |
| Brakes                          | 4.591—5.266  |
| Rear Axle—<br>Propellor Shaft   | 5.387—5.547  |
| Universal Joint—<br>Brake Drums | 5.548—5.999  |
| Front Axle                      | 6.008        |
| Steering                        | 6.508—6.999  |
| Frames—Shock<br>Absorbers       | 7.000—7.411  |
| Springs                         | 7.412—7.602  |
| Bumper                          |              |
| Chassis Sheet<br>Metal—8.000    | 8.000        |
| Tools—8.821                     | 8.821        |
| Miscellaneous                   | 9.000—16.999 |
| Cab—1st Type                    |              |
| Cab—2nd Type                    |              |
| Standard Parts                  |              |
| Numerical Index                 |              |

## CHEVROLET -- SPARE PARTS LIST -- MODEL C30 -- 30 CWT. 4X4



### C-30

THE ABOVE ILLUSTRATION SHOWS A THREE-QUARTER FRONT VIEW OF THE MODEL C-60L (3 TON 4x4 LORRY), EQUIPPED WITH A GENERAL SERVICE BODY OPTION.

THE MODEL C-30 (30 CWT. 4x4) HAS A 134" WHEELBASE AND IS SIMILAR TO THE C-60L EXCEPT FOR THE LOAD CAPACITIES AND BODY OPTIONS.

THE BODY OPTIONS AVAILABLE FOR THE C30 ARE AS FOLLOWS:

OFFICE AND LIGHT ANTI-AIRCRAFT TRACTOR

## CHEVROLET -- SPARE PARTS LIST -- MODEL C30 -- 30 CWT. 4X4

### SUGGESTIONS FOR EFFICIENT USE OF THE PARTS LIST

TO LOCATE THE LISTING OF A PART, REFER TO THE PARTS LIST UNDER THE GROUP NUMBER IDENTIFYING IT, WHICH MAY BE DETERMINED BY USING ANY OF THE FOLLOWING THREE METHODS -

1. CONSULT ALPHABETICAL INDEX AT "FRONT" OF PARTS LIST, WHICH LISTS PARTS BY NOUN AND DESCRIPTIVE NAMES AND REFERS TO THE PAGE NUMBER WHERE ALL PARTS OF SIMILAR KIND MAY BE FOUND. IF NAME OF DESIRED PART IS NOT READILY FOUND IN THE INDEX, A CORRELATED PART NAME WILL SUGGEST APPROXIMATE LOCATION.
2. CONSULT ILLUSTRATIONS IN EACH GROUP SECTION, ON WHICH GROUP NUMBERS OR PLATE REFERENCE NUMBERS ARE SHOWN DIRECTING YOU TO THE PART OR ASSEMBLY WANTED. THESE ILLUSTRATIONS AND LINE DRAWINGS MAY NOT SHOW THE EXACT PART REQUIRED, BUT ARE FOR IDENTIFICATION PURPOSES.
3. CONSULT NUMERICAL INDEX AT "BACK" OF PARTS LIST, IF A PART NUMBER IS KNOWN, USE ITS PAGE NUMBER TO LOCATE A SIMILAR PART, OR BE DIRECTED TO THE APPROXIMATE LOCATION OF CORRELATED PARTS.

THE NUMERICAL INDEX SHOWS ALL SERVICE PART NUMBERS IN CONSECUTIVE ORDER.

THE GROUP SYSTEM OF LISTING PARTS, BRIEFLY, IS AS FOLLOWS -

MAIN UNITS OF THE CAR ARE IDENTIFIED BY THE NUMERAL PRECEDING THE DECIMAL, I.E.

|  |     |
|--|-----|
| ENGINE.....                                | 0.- |
| COOLING AND OILING.....                    | 1.- |
| ELECTRICAL.....                            | 2.- |
| FUEL SYSTEM.....                           | 3.- |
| ETC. (See thumb index on first title page) |     |

INDIVIDUAL PARTS ARE ASSIGNED A GROUP NUMBER, THE FIRST NUMERAL INDENTIFYING THE MAIN UNIT WITH WHICH IT IS AFFILIATED, AND FOLLOWING THE DECIMAL IS THE SUB-GROUP NUMBER UNDER WHICH ALL PARTS OF THE SAME NAME AND FUNCTION ARE LISTED. FOR INSTANCE: GROUP 0.033: "0" INDICATES THAT IS AN ENGINE PART. ".033" IS THE LOCATION WHERE ALL PART NUMBERS OF CYLINDER BLOCKS NOW BEING SERVICED MAY BE FOUND.

ALL ILLUSTRATIONS HAVE PLATE NUMBERS. PARTS WHICH ARE ILLUSTRATED SHOW THE PLATE NUMBER IN A COLUMN FOLLOWING THE GROUP NUMBER. ON SPECIAL PARTS PECULIAR TO D.N.D. VEHICLES ON WHICH GROUP NUMBERS ARE NOT AVAILABLE, THE ITEM NUMBER IS ALSO SHOWN, I.E. 20-3 MEANS THE PART IS SHOWN ON PLATE NUMBER 20, ITEM NUMBER 3.

## CHEVROLET -- SPARE PARTS LIST -- MODEL C30 -- 30 CWT. 4X4

AN ASTERISK (\*) PRECEDING A PART NUMBER DENOTES THAT THE PART ISpecular TO CANADIAN MILITARY PATTERN VEHICLES.

### INSTRUCTIONS FOR ORDERING PARTS

ALWAYS GIVE PART NUMBER, NAME AND MODEL OF EACH PART ORDERED.

THE NUMBERS SHOWN ON THE ILLUSTRATIONS ARE FOR REFERENCE PURPOSES ONLY. AFTER IDENTIFYING THE PART REQUIRED REFER TO THE LIST OF PARTS AND ORDER BY PART NUMBER AND DESCRIPTION.

### "RIGHT" AND "LEFT" DESCRIPTIONS

THE DESIGNATION "RIGHT" AND "LEFT" AS USED IN THIS PARTS LIST ARE DETERMINED FROM THE DRIVER'S POSITION.

### UNIDENTIFIED PARTS

IF YOU CANNOT IDENTIFY THE PART REQUIRED, BY PART NUMBER AND DESCRIPTION, USE ONE OF TWO ALTERNATIVES:

- A. SUBMIT THE OLD PART PROPERLY TAGGED WITH AS COMPLETE A DESCRIPTION OF THE ITEM AS POSSIBLE INCLUDING THE MODEL NUMBER. ALSO INDICATE THE LOCATION OF THE PART ON THE VEHICLE.
- B. FURNISH A SKETCH SHOWING THE SHAPE AND APPROXIMATE DIMENSIONS. ALSO GIVE COMPLETE INFORMATION INCLUDING MODEL NUMBER AND MENTION OR DRAW THE LOCATION OF THE PART ON THE VEHICLE.

WHENEVER IN DOUBT ABOUT THE PARTS REQUIRED, GIVE THE CHASSIS SERIAL NUMBER WHICH IS SHOWN ON A PLATE (ILLUSTRATED BELOW) LOCATED ON THE RIGHT SIDE OF THE ENGINE ENCLOSURE, IN THE CAB ON FIRST JOBS, AND LOCATED ON TOP OF INSTRUMENT PANEL ON LATER JOBS.

|                               |                       |
|-------------------------------|-----------------------|
| GENERAL MOTORS OF CANADA LTD. |                       |
| OSHAWA, CANADA                |                       |
| CHASSIS MODEL                 | C-60448 - M - W       |
| CAB MODEL                     | 13                    |
| CHASSIS SERIAL                | 2844300960            |
| ENGINE SERIAL                 | XR3678541             |
| ORDER No.                     | SPL/MECH - 2037 (4x4) |
| DATE OF MFG.                  | MCH. 23 1942          |

**CHEVROLET -- SPARE PARTS LIST -- MODEL C30 -- 30 CWT. 4X4****ALPHABETICAL INDEX**

| Page                                    | Page |   |     |
|---|------|---|-----|
| <b>A</b>                                |      |   |     |
| ACCELERATOR CONTROL.....                | 62   | CONNECTING ROD.....                         | 12  |
| AIR CLEANER.....                        | 61   | CONNECTING ROD, steering.....               | 144 |
| AIR CLEANER, transfer case.....         | 79   | CONNECTOR, valve rocker shaft oil.....      | 32  |
| AMMETER.....                            | 46   | CORE, radiator.....                         | 21  |
| ARM, valve rocker.....                  | 10   | COUNTERSHAFT AND GEARS.....                 | 77  |
| AXLE, front.....                        | 130  | COVER, crankcase - front end.....           | 8   |
| AXLE, rear.....                         | 115  | COVER, power take-off.....                  | 78  |
| <b>B</b>                                |      | COVER, radiator grille.....                 | 21  |
| BAFFLES, radiator.....                  | 25   | COVER, transmission.....                    | 75  |
| BALANCER, crankshaft.....               | 14   | COVER, valve rocker.....                    | 11  |
| BATTERY.....                            | 39   | CRANKSHAFT.....                             | 14  |
| BEARINGS, crankshaft main.....          | 7    | CRANK, starting.....                        | 8   |
| BEARINGS, differential - rear axle..... | 121  | CYLINDER BLOCK.....                         | 7   |
| BEARINGS, pinion - front axle.....      | 132  | CYLINDER, brake main.....                   | 104 |
| BEARINGS, pinion - rear axle.....       | 118  | CYLINDER HEAD.....                          | 9   |
| BEARINGS, rear wheel.....               | 125  | <b>D</b>                                    |     |
| BELT, fan.....                          | 19   | DEFROSTER.....                              | 184 |
| BLOCK, cylinder.....                    | 7    | DIFFERENTIAL & CARRIER, front.....          | 131 |
| BOARD, running.....                     | 168  | DIFFERENTIAL & CARRIER, rear.....           | 120 |
| BOLTS, body hold down.....              | 181  | DIFFERENTIAL CASE, rear axle.....           | 120 |
| BOLTS, spring centre.....               | 158  | DISTRIBUTOR.....                            | 42  |
| BOX, battery.....                       | 40   | DISTRIBUTOR, oil.....                       | 30  |
| BRACKET, front license.....             | 160  | DRUM, brake.....                            | 124 |
| BRACKET, front spring.....              | 148  | <b>E</b>                                    |     |
| BRACKET, starting crank.....            | 146  | ENDS, steering - front axle.....            | 133 |
| BRACKET, steering gear frame.....       | 149  | ENGINE.....                                 | 6   |
| BRACKET, fuel tank.....                 | 59   | ENGINE MOUNTING.....                        | 6   |
| BRACKET, headlamp.....                  | 56   | <b>F</b>                                    |     |
| BRACKET, transfer case support.....     | 87   | FAN.....                                    | 19  |
| BRAKE FLUID.....                        | 108  | FAN, generator.....                         | 36  |
| BRAKES, front.....                      | 112  | FENDER, front.....                          | 164 |
| BRAKES, rear.....                       | 112  | FILTER, fuel.....                           | 69  |
| BRAKE PEDAL.....                        | 104  | FILTER, oil.....                            | 31  |
| BRAKE, propeller shaft hand.....        | 111  | FITTINGS, oil pipe.....                     | 27  |
| BRAKE, winch.....                       | 96   | FLANGE, drive pinion - front axle.....      | 133 |
| BUMPER, clutch pedal.....               | 181  | FLANGE, propeller shaft - front.....        | 76  |
| BUMPER, front.....                      | 161  | FLANGES, propeller shaft.....               | 121 |
| <b>C</b>                                |      | FLANGES, transfer case propeller shaft..... | 86  |
| CABLES, battery.....                    | 39   | FLUID, brake.....                           | 108 |
| CABLES, brake.....                      | 108  | FLUID, shock absorber.....                  | 154 |
| CABLE, winch.....                       | 99   | FLYWHEEL.....                               | 14  |
| CAMSHAFT.....                           | 12   | FORK, transfer case gear.....               | 85  |
| CAP, crankcase ventilator.....          | 27   | FRAME.....                                  | 145 |
| CAP, front hub.....                     | 125  | <b>G</b>                                    |     |
| CARBURETOR.....                         | 66   | GAUGES, fuel.....                           | 59  |
| CARRIER, front axle differential.....   | 131  | GAUGE, heat indicator.....                  | 20  |
| CARRIER, rear axle differential.....    | 120  | GAUGE, oil pressure.....                    | 31  |
| CARRIER, transfer case declutch.....    | 84   | GEAR, main drive or clutch.....             | 76  |
| CARRIER, tire.....                      | 160  | GEAR & PINION, drive - front.....           | 132 |
| CASE, differential - rear axle.....     | 120  | GEAR & PINION, drive - rear.....            | 121 |
| CASE, transmission.....                 | 75   | GEAR, steering.....                         | 140 |
| CASE, transfer.....                     | 78   | GEAR, reverse idler.....                    | 78  |
| CHAINS, tire.....                       | 173  | GEARS, speedometer.....                     | 76  |
| CHOKE CONTROL.....                      | 62   | GEARSHIFT.....                              | 74  |
| CLEVIS, front towing.....               | 147  |   |     |
| CLIPS, spring leaf.....                 | 158  |   |     |
| CLUTCH.....                             | 16   |   |     |
| CLUTCH RELEASE.....                     | 15   |   |     |
| COIL, ignition.....                     | 35   |   |     |
| CONDENSERS, radio.....                  | 48   |   |     |

**CHEVROLET -- SPARE PARTS LIST -- MODEL C30 -- 30 CWT. 4X4****ALPHABETICAL INDEX—(Cont'd)**

|  | Page |  | Page |
|--|------|--|------|
| <b>G (Cont'd)</b>                      |      | <b>M (Cont'd)</b>                        |      |
| GEARS, timing.....                     | 15   | MOUNTING, engine.....                    | 6    |
| GEARS, transfer case driven.....       | 83   | MUFFLER.....                             | 64   |
| GEARS, transfer case idler.....        | 83   |  |      |
| GEAR, transfer case main drive.....    | 82   |  |      |
| GEARS, transmission.....               | 77   |  |      |
| GENERATOR.....                         | 37   |  |      |
| GRILLE, radiator.....                  | 23   | N  |      |
| GROMMETS.....                          | 183  | NUT, propeller shaft.....                | 123  |
| GUARD, radiator.....                   | 160  |  |      |
|  |      | O  |      |
|  |      | OIL SEAL, inner - front axle shaft.....  | 133  |
| <b>H</b>                               |      | OUTLET, water.....                       | 20   |
| HANGER, front spring rear.....         | 149  |  |      |
| HANGER, rear spring.....               | 148  |  |      |
| HEAD, cylinder.....                    | 9    |  |      |
| HEADLAMPS.....                         | 53   |  |      |
| HEATER, body gasoline.....             | 179  | P  |      |
| HEATER, dash.....                      | 177  | PAN, engine side.....                    | 164  |
| HOOD.....                              | 162  | PAN, oil.....                            | 26   |
| HORN.....                              | 57   | PAN, winch splash.....                   | 95   |
| HORN, front spring.....                | 148  | PEDAL, brake.....                        | 104  |
| HOSE, brake.....                       | 106  | PEDAL, clutch.....                       | 15   |
| HOSE, radiator.....                    | 20   | PINS AND BUSHINGS, piston.....           | 13   |
| HOUSING, clutch.....                   | 14   | PIPE, exhaust.....                       | 64   |
| HOUSING, front axle.....               | 130  | PIPES, fuel.....                         | 60   |
| HOUSING, rear axle.....                | 117  | PIPE, muffler tail.....                  | 65   |
| HUB, front wheel.....                  | 139  | PIPES, oil.....                          | 27   |
| HUB, rear wheel.....                   | 124  | PIPE, steam relief.....                  | 26   |
|  |      | PIPING, brake.....                       | 106  |
| <b>I</b>                               |      | PISTONS.....                             | 13   |
| INSTRUMENT MOUNTING.....               | 181  | PLATE, gearshift instruction.....        | 78   |
|  |      | PLATE, radiator name.....                | 26   |
| <b>J</b>                               |      | PLUGS, spark.....                        | 36   |
| JOINT & BALL UNIVERSAL.....            | 121  | POWER TAKE-OFF.....                      | 85   |
| JOINT, winch universal.....            | 98   | PUMP, fuel.....                          | 69   |
|  |      | PUMP, oil.....                           | 28   |
| <b>K</b>                               |      | PUMP, power tire.....                    | 173  |
| KIT, first aid.....                    | 184  | PUMP, water.....                         | 19   |
|  |      | PULLEY, generator.....                   | 36   |
| <b>L</b>                               |      | PULLEY, water pump and fan.....          | 19   |
| LAMPS, head.....                       | 53   |  |      |
| LAMP, instrument.....                  | 57   | <b>R</b>                                 |      |
| LAMP, rear axle.....                   | 53   | RADIATOR.....                            | 21   |
| LAMP, tail.....                        | 49   | REGULATOR, current voltage.....          | 45   |
| LAMP, side.....                        | 49   | RELAY, current circuit.....              | 46   |
| LAMP, stop.....                        | 49   | RETAINER, transmission rear bearing..... | 75   |
| LEVER, hand brake.....                 | 103  | RINGS, piston.....                       | 13   |
| LEVER, winch hand brake.....           | 97   | RODS, brake.....                         | 108  |
|  |      | ROD, connecting.....                     | 12   |
| <b>M</b>                               |      | ROD, steering connecting.....            | 144  |
| MANIFOLD, exhaust.....                 | 64   | ROD, oil level indicator.....            | 27   |
| MANIFOLD, intake.....                  | 60   | ROD, valve push.....                     | 12   |
| MEMBER, frame cross.....               | 146  | RODS, winch hand brake pull.....         | 98   |
| MEMBER, frame side.....                | 145  | ROLLER, winch front cable.....           | 100  |
| METERING VALVE, engine ventilator..... | 30   | ROLLER, winch rear cable.....            | 101  |
|  |      | ROPE, tow.....                           | 173  |
|  |      |  |      |
|  |      | <b>S</b>                                 |      |
|  |      | SEAL, inner oil - front axle shaft.....  | 133  |
|  |      | SHAFT, axle - rear.....                  | 117  |
|  |      | SHAFT, hand brake cross.....             | 108  |
|  |      | SHAFTS, propeller.....                   | 118  |

**CHEVROLET -- SPARE PARTS LIST -- MODEL C30 -- 30 CWT. 4X4****ALPHABETICAL INDEX—(Cont'd)**

| Page                                 | Page                                     |     |
|--------------------------------------|--|-----|
| <b>S (Cont'd)</b>                    | <b>T (Cont'd)</b>                        |     |
| SHAFT, transfer case declutch.....   | 84                                       |     |
| SHAFT, transfer case driven.....     | 83                                       |     |
| SHAFT, transfer case idler.....      | 83                                       |     |
| SHAFT, transfer case main drive..... | 82                                       |     |
| SHAFT, reverse idler.....            | 78                                       |     |
| SHAFT, transmission main.....        | 77                                       |     |
| SHAFT, valve rocker arm.....         | 10                                       |     |
| SHAFT, winch hand brake cross.....   | 98                                       |     |
| SHAFT, winch propeller.....          | 98                                       |     |
| SHEAVE, winch cable.....             | 102                                      |     |
| SNELL, radiator.....                 | 23                                       |     |
| SHIFTER, transfer case gear.....     | 85                                       |     |
| SHOCK ABSORBER.....                  | 149                                      |     |
| SHROUD, radiator fan.....            | 25                                       |     |
| SPEEDOMETER.....                     | 75                                       |     |
| SPEEDOMETER GEARS.....               | 76                                       |     |
| SPEEDOMETER SHAFTS.....              | 76                                       |     |
| SPRINGS, front.....                  | 154                                      |     |
| SPRINGS, rear.....                   | 157                                      |     |
| SPRING ATTACHING PARTS, front.....   | 156                                      |     |
| SPRING ATTACHING PARTS, rear.....    | 159                                      |     |
| STANDARD STOCK.....                  | 224                                      |     |
| STARTER CONTROL.....                 | 32                                       |     |
| STARTING MOTOR.....                  | 33                                       |     |
| STEERING GEAR.....                   | 140                                      |     |
| STOVE, chassis heater.....           | 180                                      |     |
| SUPPORT, engine rear.....            | 148                                      |     |
| SUPPORT, radiator.....               | 22                                       |     |
| SWITCH, dimmer.....                  | 45                                       |     |
| SWITCH, ignition.....                | 35                                       |     |
| SWITCHES, instrument panel.....      | 183                                      |     |
| SWITCH, lighting.....                | 45                                       |     |
| SWITCH, stop lamp.....               | 45                                       |     |
| <b>T</b>                             | <b>U</b>                                 |     |
| TAPPET.....                          | 12                                       |     |
| TANK, fuel.....                      | 58                                       |     |
| TANK, primer fuel.....               | 59                                       |     |
| TANK, radiator overflow.....         | 25                                       |     |
| THERMOSTAT.....                      | 23                                       |     |
| <b>V</b>                             | <b>VACUUM CONTROL</b>                    |     |
|                                      | 44                                       |     |
|                                      | <b>VALVES</b>                            | 9   |
|                                      | <b>VALVE, engine ventilator metering</b> | 30  |
|                                      | <b>VALVES, exhaust manifold</b>          | 64  |
|                                      | <b>VALVE ROCKER SHAFT OIL CONNECTOR</b>  | 32  |
|                                      | <b>VENT, front axle</b>                  | 131 |
|                                      | <b>VENT, rear axle</b>                   | 120 |
|                                      | <b>VENTILATOR, crankcase</b>             | 29  |
| <b>W</b>                             | <b>WHEELS</b>                            | 123 |
|                                      | <b>WINCH</b>                             | 93  |
|                                      | <b>WINCH ATTACHING PARTS</b>             | 95  |
|                                      | <b>WIRES, spark plug</b>                 | 36  |
|                                      | <b>WIRING</b>                            | 47  |

**CAB**

| 1st Type                             | 2nd Type |
|--------------------------------------|----------|
| CLIP, rifle.....                     | 192      |
| COVER ASSEMBLY, body waterproof..... | 204      |
| DOORS.....                           | 192      |
| FLOOR.....                           | 195      |
| FRONT AND SIDES.....                 | 197      |
| MIRROR, rear view.....               | 186      |
| PANEL, instrument.....               | 196      |
| PANELS, roof and back.....           | 191      |
| SEATS.....                           | 200      |
| VENTILATOR.....                      | 200      |
| WINDSHIELD.....                      | 202      |
| WIPER, windshield.....               | 186      |
| <b>CLIP, rifle</b>                   | 210      |
| <b>DOORS</b>                         | 210      |
| <b>FLOOR</b>                         | 214      |
| <b>FRAME, lower</b>                  | 221      |
| <b>HATCH, roof</b>                   | 209      |
| <b>HOUSING, motor</b>                | 216      |
| <b>MOUNTING, cab</b>                 | 222      |
| <b>MOUNTING, front end shell</b>     | 221      |
| <b>PANEL, instrument</b>             | 216      |
| <b>PANELS, roof and back</b>         | 208      |
| <b>SEATS</b>                         | 218      |
| <b>SHELL, front end</b>              | 215      |
| <b>SHROUD</b>                        | 223      |
| <b>VENTILATOR, side</b>              | 217      |
| <b>WINDSHIELD</b>                    | 219      |

