
# TM 9-800

WAR DEPARTMENT TECHNICAL MANUAL

115

# 6-TON PAYLOAD, 10-TON GROSS, 2-WHEEL, VAN SEMITRAILER



WAR DEPARTMENT

16 OCTOBER 1944

# WAR DEPARTMENT TECHNICAL MANUAL

# TM 9-888

This manual supersedes TM 9-888, 18 December 1943, and OFSTB 800-8, 30 March 1943.

# 6-TON PAYLOAD, 10-TON GROSS, 2-WHEEL, VAN SEMITRAILER



WAR DEPARTMENT

16 OCTOBER 1944

**RESTRICTED** DISSEMINATION OF RESTRICTED MATTER—The information contained in restricted documents and the essential characteristics of restricted material may be given to any person known to be in the service of the United States and to persons of undoubted loyalty and discretion who are cooperating in Government work, but will not be communicated to the public or to the press except by authorized military public relations agencies. (See also paragraph 23 b, AR 380-5, 15 March 1944.)

#### WAR DEPARTMENT

Washington 25, D. C., 16 October 1944

TM 9-888, 6-ton Payload, 10-ton Gross, 2-wheel, Van Semitrailer, is published for the information and guidance of all concerned.

[A.G. 300.7 (30 Sep 44)]
By Order of the Secretary of War:

G. C. MARSHALL, Chief of Staff.

#### OFFICIAL:

J. A. ULIO,

Major General,

The Adjutant General.

DISTRIBUTION: Armies (10); Corps (10); Sv C (10); Dept (10); D (2); Tech Sv (2); Arm and Sv Boards (2); P, C, or Stas (1); Gen and Sp Sv Schs (10); Ord Decentralized Sub-O (3); PE's "Mark for Ord O" (5); H and R Points (5); Ord Dist O (5); Ord Reg O (3); Ord Dist Br O (3); Ord Estabs (5).

# CONTENTS

# PART ONE-INTRODUCTION

			Paragraphs		Pages
SECTION	I.	General	1-	2	5-9
	II.	Description and data	3-	4	10-14
	III.	Tools, parts, and accessories		5	14
I	PART T	WO-OPERATING INSTRU	стіо	NS	
SECTION	IV.	General		6	15
	V.	Service upon receipt of equipment	7-	9	15–16
	VI.	Controls and operation	10-	12	16-23
	VII.	Operation under unusual conditions		13	23-24
	VIII.	Demolition to prevent enemy use	14-	15	24–25
PAR	T THR	EE-MAINTENANCE INST	RUC1	OI	IS
SECTION	IX.	General		16	26
	X.	Special organizational tools and equipment		17	26
	XI.	Lubrication	18-	19	26-38
	XII.	Preventive maintenance services	20-	26	38–55
	XIII.	Trouble shooting			55-62
	XIV.	Tires, wheels, hubs, wheel bearings, and brake drums		47	62–69
	xv.	Brakes	48-	54	69-7,3
	XVI.	Brake operating system	55-	65	73-86
	XVII.	Suspension	66-	75	86–101
	XVIII.	Landing gear	76–	82	101-107
	XIX.	Landing gear operating mechanism (retractable	83-	96	107–109
		type) © PAPERPRINT.BE 2017	03-	00	10/-109

# PART THREE-MAINTENANCE INSTRUCTIONS (Cont'd)

			Paragraphs	Pages				
SECTION	XX.	Electrical system	87- 98	109-123				
	XXI.	Spare wheel and carrier	99-102	123-124				
	XXII.	Body	103-111	125-129				
	XXIII.	Frame and upper fifth wheel	112–113	129				
PART FOUR-AUXILIARY EQUIPMENT								
SECTION	XXIV.	General	114	130				
PART FIVE-REPAIR INSTRUCTIONS								
SECTION	XXV.	General	115	131				
	XXVI.	and brake lining						
		replacement	116-118	131–134				
	XXVII.	Landing gear (rigid type)	119-122	134–138				
APPENDIX								
SECTION	XXVIII.	Shipment and limited						
		storage	123-125	138-143				
	XXIX.	References	126-128	143-145				
	INDEX .			146				

#### RESTRICTED

This manual supersedes TM 9-888, 18 Dec 1943, and OFSTB 800-8, 30 March 1943.

# PART ONE-INTRODUCTION

### Section I

## GENERAL

### SCOPE.

- a. These instructions are published for the information and guidance of all concerned. They contain information on operation and maintenance of the following van-type semitrailers, as well as descriptions of major units and their functions in relation to other components of the vehicles.
- (1) Model STV-620 (American Bantam Car Company).
- (2) Model DF-233-V (American Body and Trailer Company).
- (3) Model C-15-935A (Carter Manufacturing Company).





Figure 1—Right Front View (American Bantam Model STV-620)

© PAPERPRINT BE 2017



- (4) Model E-14 (Dorsey Brothers).
- Model 1-ORD (Kentucky Manufacturing Company).
- (6) Model KV-10 (Olson Manufacturing Company).
- (7) Model LV-10 (Olson Manufacturing Company).
- (8) Model 400-W (Strick Company).
- (9) Model T-8-D (Timpte Brothers).
- (10) Model GSW-4 (Utility Trailer Manufacturing Company).
- b. This manual is arranged in five parts: Part One, Introduction; Part Two, Operating Instructions; Part Three, Maintenance Instructions; Part Four, Auxiliary Equipment, and Part Five, Repair Instructions.
- c. The appendix at the end of the manual contains instructions for shipment and limited storage, and a list of references including standard nomenclature lists, technical manuals and other publications applicable to the vehicle.

### 2. RECORDS.

- a. Forms and records applicable for use in performing prescribed operations are listed below with a brief explanation of each:
- (1) W.D., A.G.O. FORM NO. 7360, ARMY MOTOR VEHICLE OPERATOR'S PERMIT (applies to towing vehicle only). This form will be issued by commanding officers of posts, camps, stations, or organizations, to all operators of military vehicles who have passed the driver's examination (TM 21-300) and are qualified to drive the particular vehicles noted on the permit.
- (2) WAR DEPARTMENT LUBRICATION ORDER. War Department Lubrication Order No. 789 prescribes lubrication maintenance for this vehicle. A Lubrication Order is issued with each vehicle, and is to be carried with it at all times.
- (3) STANDARD FORM NO. 26, DRIVER'S REPORT—ACCI-DENT, MOTOR TRANSPORTATION (applies to towing vehicle only). One copy of this form will be kept with the vehicle at all times. In case of an accident resulting in injury or property damage, it will be filled out by the driver on the spot, or as promptly as practical thereafter.
- (4) WAR DEPARTMENT FORM NO. 48, DRIVER'S TRIP TICKET AND PREVENTIVE MAINTENANCE SERVICE RECORD. This form, properly executed, will be furnished to the driver when his vehicle is dispatched on nontactical missions. The driver and the official user of the property of the




Figure 3-Right Side View (Olson Model LV-10)